




### **Ozone Timer Operating Instructions:**

1. First time use—connect to AC and allow to charge. When fully charged press the reset key.
2. The timer switch comes in 24h mode. If you would like to change to 12h mode press and hold the  key for 5 seconds. The LCD will display AM. To return to 24h mode, press the  key for 5 seconds.

**(Not all models have the 24h/12h switching option)**

### 3. Programming:

Step	Key	Programming
1	Press P	Setting “1 ON”
2	Press D+	Select days of week
3	Press H+/M+	Set hour and minutes
4	Press P	Setting “1 OFF”
5	Press P	Select days of week
6	Press H+/M+	Set hours and minutes
7	Repeat steps 2-6	Set 2-8 on/off time
8	Press 	End

### **Note:**




To cancel setting, press “MANUAL”, “\_ \_ \_ \_” will be displayed on LCD to confirm cancel. Press “MANUAL” again to resume initial setting.

### **10 different mode options:**

1. MO TU WE TH FR SA SU; 2. MO TU WE TH FR; 3. SA SU; 4. MO;
5. TU; 6. WE; 7. TH; 8. FR; 9. SA; 10. SU

\*\*If you don't need 8 time settings press the  key to End\*\*

### 4. Setting the Clock

- (1) Press  and D+ together to set the day of the week
  - (2) Press  and H+ together to set the hour
  - (3) Press  and M+ together to set the minutes
5. Press “MANUAL” key to select ON/OFF/AUTO setting.  
ON setting runs system continuously  
OFF setting turns system completely OFF  
AUTO setting runs your programmed days and times